



Custom Settings: Power-On Channel

What is the Power-On Channel?

You can set your Digital cable box so that every time you turn it on, your TV automatically tunes to your Favorite Channel.

When your cable box was installed, a Power-On Channel may have been set up. These instructions show you how to change it very easily to suit your needs.

Setting Up the Power-On Channel

1. Press the **SETTINGS** button on your remote control to display the **Quick Settings** menu on your TV screen.
2. Press the **A** button to display the detailed **General Settings** menu.
3. Press the **UP** or **DOWN** arrow buttons to find the **Power-On Channel**. Then press the **SELECT** button.
4. Press the **UP** or **DOWN** arrow buttons to find the channel you want. You can also scroll faster with the **PAGE + / -** button.
5. Once you have found the channel you want, press the **A** button to accept your choice.

Choosing Last Channel

1. You can also select **Last Channel** as your **Power-On Channel**. Your TV will tune to the last channel you watched before turning off the cable box.
2. When you are in the **Power-On Channel** option in the **General Settings** menu, scroll past the list of channels to find the choice called **Last Channel**.
3. Once you have selected **Last Channel**, press the **A** button to accept your choice.

How to Use the Power-On Channel

Once you have set up your **Power-On Channel**, you don't have to do anything else. Now, every time you turn on your cable box, the TV will automatically tune to your **Power-On Channel**.

Tip:

The **Power-On Channel** setting works only if you turn your TV off and on using your cable box (by pressing the **CBL** button).