

Connecting a Tuning Adapter to your TiVo HD DVR


Note: This diagram does not show audio/video connections to your HDTV and home theater system. For complete setup information, please see the **Start Here poster** that came with your TiVo DVR.

What is a Tuning Adapter?

A Tuning Adapter is a small external box provided by your cable company that connects to your TiVo HD, TiVo HD XL, or TiVo Series3 DVR. It enables the DVR to recognize Switched Digital Video channels.

Switched Digital Video is a way to add new channel lineups on existing bandwidth by having channels “switch off” when no one requests them and “switch on” when someone wants to watch them. To make all this switching happen, your TiVo HD DVR needs a Tuning Adapter.

To learn more, or to get help, visit tivo.com/switched.



Follow these steps:

- 1 If your TiVo HD DVR is already connected to your HDTV and/or home theater system, great! Don't change any of these audio and video connections. (If not, begin with the **Start Here poster**, then return to this diagram.)
- 2 Connect the Coaxial cable from the wall (from your cable TV provider) to the **CABLE IN** jack on the Tuning Adapter (instead of the **CABLE IN** jack on the TiVo DVR).
- 3 Connect another Coaxial cable from the Tuning Adapter's **CABLE OUT** jack to the TiVo DVR's **CABLE IN** jack.
- 4 Connect the USB A/B cable from the **back** of the Tuning Adapter to one of the TiVo DVR's **USB ports**. (It doesn't matter which one.)
- 5 Connect all power cords, then turn on the Tuning Adapter and your TV. Follow the on-screen instructions to test your channels and complete Tuning Adapter setup.