

Self-Installation Kit Installation Instructions

HD or HD DVR Converter

Use the connection diagram and follow the below steps to connect the Digital Converter.

1. Unplug all electrical devices before connecting the Digital Converter.
2. Connect the coaxial cable coming from the wall to the Cable In on the back of the Digital Converter.
3. Connect the video and audio cables using one of the following.

Component Cable: Connect the green connector on the HDTV to the green connector on the Digital Converter; connect the blue connector on the HDTV to the blue connector on the Digital Converter; and connect the red connector on the HDTV to the red connector on the Digital Converter. Connect the left audio (white) connector on the HDTV to the left audio (white) connector on the Digital Converter, and connect the right audio (red) connector on the HDTV to the right audio (red) connector on the Digital Converter.

HDMI Cable: HDMI offers higher quality HD video than component video. If your TV has an HDMI input, this is for both audio and video. Connect an HDMI cable to the TV and to the HDMI connector on your Digital Converter. HDMI output provides video and audio, so no separate audio connection is required if you plan to use your TV's speakers as the primary source.

DVI Cable: If your TV has a DVI input, connect a DVI-to-HDMI adapter or cable to the HDMI connector on the Digital Converter and the DVI-HDTV connector on your TV. DVI does not provide audio. A separate audio connection must be made.

4. Plug the Digital Converter and the HDTV into an AC power source.

Important: Do not press the Power key on the Digital Converter yet.

Note: You may be able to reduce the risk of damage from voltage surges, which can be caused by lightning storms and power outages, by plugging the Digital Converter into a surge protector.

5. Turn on your TV. Set it to the correct Input on your HDTV to match your Cable Box Output.
6. Wait several minutes for the Digital Converter to receive the latest software, programming and service information. When the current time displays on the front panel of the Digital Converter, that indicates that the update is complete:

Note: If four dashes or a Not Authorized statement displays, please call your service provider to get the Digital Converter authorized.

7. To begin watching TV, press Power on the front panel of the Digital Converter, or press Power on the remote control.

